



RELEASED
12/22/22

PPP

Part Number	K10111
Description	Saddle Kit for D206-642-111/-113

Box Part Number	N/A	Dimension	N/A
			L x W x H
Other Packaging	Foam		
Logo Decals			

Packaging Instructions and Decal Placement

K10111

Place kit in D206-642-111/-113 box. Place some more foam on top to prevent movement.

Add hardware and saddle. Seal box and apply label D2729-3 as per instructions in QSI 014 section 4.5

Note: Fill all voids of box with foam to prevent movement.

D2729-1

D2729-3

N/A

	Dart Aerospace Ltd. 1270 Aberdeen Street Hawkesbury, ON K6A 1K7 CANADA TEL.: 1 613 632-5200
K10111 SADDLE KIT CHG003	
INCLUDES PARTS FOR:	
D206-642-111	CHG007
D206-642-113	CHG002
B/N: BXXXXX	

Revision: G
Date: 12.01.30

H:\Admin-qaliso\forms\PPP-1.Rev.A